

## Choosing Your Vibo Elite Wirework

First, measure the width of the wardrobe that will be fitted with the wirework.

### Full Width Pullouts...

Full width pullouts are mounted on runners fixed to either side of the wardrobe and pull out like an internal drawer. The full width pullouts are fully customisable with a wide range of different inserts available to mount within an Adjustable Wardrobe Frame.

- 1, Choose the Adjustable Wardrobe Frame to suit the width of your wardrobe.
- 2, Once you have chosen the Adjustable Wardrobe Frame, choose inserts to mount within it. Depending on the width of the chosen Adjustable Wardrobe Frame, it's possible to mount more than one insert within it.
- 4, Choose from the following inserts...

*Wire Baskets (Widths: 305mm, 410mm, 490mm, 730mm)*

*Shoe Racks (Widths: 390mm, 470mm)*

*Trouser Holders (Widths: 455mm, 719mm)*

*Steel Trays (Width: 305mm)*

*Laundry Basket (Width: 460mm)*

- 5, Choose any accessories you may require. (Tie & belt organisers, none slip mats, tufted mats, etc.)



### Side Mounted Pullouts

Side mounted pullouts are fixed to one side of the wardrobe. Depending on the width of your wardrobe and the pullouts you choose, it is possible to fix side mounted pullouts on both sides of your wardrobe.

*Choose from the following Side Mounted Pullouts...*

*Shoe Racks*

*Tie & Belt Holder*

*Pivoting Mirror with optional Multipurpose Tray.*

Choose any accessories you may require. (None slip mats, tufted mats, etc.)

