




1.




1.

Make sure the soft closer is set forward in this position (if not working correctly this will be set further back)

2.

Locate the activator (pic shows a LH version of a Smart Corner)



2.

3.

Adjust the height of the activator by using a 4mm Allen key, turning anti-clockwise until finger tight (this raises the bracket)

Close the door & this should now be set correctly

3.

